

## Los swm nrog koj lub Chromebook

Daim ntawv no muaj ntaubntawv qhia rau koj txog koj lub Chromebook. Yog koj muaj tej yam lus nug dabtsi no thov tivtoj helpdesk ntawm (916) 566-7802, losyog sau ntawv email xa tuaj rau peb ntawm TechSupport@twinriversusd.org

Los taws lub Chromebook, qheb daim npog (the lid). Yog nws tseem tsis taws sim nias lub pob power nyob ceskaum saum toj sab xis ntawm qhov keyboard. Yog koj muaj ib lub 3189 Chromebook model, lub pob power nyob rau sab xis ntawm lub Chromebook. Los saib seb koj lub Chromebook yog hom twg, tus quav model kuj nrhiav tau nyob sab hauv qab ntawm lub Chromebook.

### Txuas koj lub Chromebook Mus rau ib lub Wireless Network

Thaum koj taws koj lub Chromebook thawj zaum nram tsev, ib soblus yuav tshwm tuaj nyob ntawm koj daim iav screen: **Network not available**. Hauv qab ntawm soblus ntawd yuav muaj ib cov wireless networks npe uas txuas tau nrog.

Yog koj muaj ib qho wireless internet txuas nyob hauv tsev, koj qhov wireless network lub npe yuav tshwm nrog cov npe ntawd.

1. Nyem koj qhov wireless network lub npe thiab ib daim window yuav tshwm tuaj.
2. Nyob hauv qhov chaw seem ntawm **Password**, ntaus lolus zais ntawm koj qhov wireless internet connection.
3. Thaum no lawm nyem **Connect**
4. Nws yuav siv ob peb chib (second) los txuas.
5. Thaum nws txuas lawm yuav xa koj mus rau ib qho rau npe nkag (login) ntawm daim screen.
6. Ntaus rau hauv, koj qhov **Student ID** thiab nyem **Next**.
7. Ntaus rau hauv, koj qhov **Password** nyem **Next**.
8. Cia li ib feeb ntau rau nws npaj lub desktop thiab cov apps.
9. Tam sim no koj siv tau koj lub Chromebook lawm.

### Chromebook Keyboard cov pob ntawv saum toj

	Xauv lub Chromebook ( <b>Tsuas yog model 3189</b> )
	Lub Pob Power ( <b>Tsuas yog models 5190, 3100, 3180, 3120</b> )
	Mus rau nplooj dhau los hauv koj qhov browser keebkwm
	Mus rau nplooj tom ntej hauv koj qhov browser keebkwm
	Rov qheb dua nplooj uas koj tab tom nyob
	Zais cov tabs thiab qhov launcher uas qheb loj loj puv daim iav (full-screen) Immersivemode
	Qheb tagnrho cov windows nyob tus quav Overview mode
	Ua kom daim screen tsaus
	Ua kom daim screen ci zog
	Tua suab
	Tso suab kom yau
	Tso suab kom nrov tuaj



### Cov kev pab kom nyabxeeb:

- Tsis txhob qhia koj lub computer lolus zais (password) rau leej twg.
- Tsis txhob kaw koj lub Chromebook thaum tseem muaj khoom nyob sab hauv.
- Tsis txhob tso dabtsi nyob saum toj ntawm koj lub Chromebook.
- Tsis txhob noj lossis haus dej nyob ntawm koj lub Chromebook.